

Cleaning Instructions: Fireclay Sinks

Refer to this document for instructions on how to properly clean your Pelican fireclay sink.

Info

To maintain the appearance of this product, we recommend it should be cleaned using a soft cloth and a non-abrasive cleaning product. A simple solution of warm water and a mild liquid non-antibacterial detergent generally does an excellent job. Ensure that the product is rinsed thoroughly and wiped dry.

Note

Never use any form of abrasive cleaner or applicator, as they often contain sand or silica and will eventually scratch the surface. Any other cleaning action will invalidate your warranty. Please do not over-tighten any fittings, as this may cause the surface of your ceramic sink to crack.

Care

The gloss surface of the sink is susceptible to damage from sharp and metallic objects. The worst offender is metal cutlery. Try to avoid metal objects coming into contact with the surface by using protective plastic bowls, wire grid cutlery holders, and drainers with non-abrasive bases.

Features

- Odor-resistant
- Heat-resistant
- Impact-resistant
- Chemical-resistant
- Dirt and stain-resistant
- Natural material
- 10 year guarantee
- Waste disposal compatible
- Recyclable



Pelican Int'l | 6140 Ulmerton Rd.
Clearwater, FL 33760
Office: (727) 388-9895
Fax: (727) 362-1281
www.pelicanFL.com

